



Function card - Sound on/off

Function card used to activate Flexlock into emitting a beep each time it is locked or unlocked.

Card used to activate Flexlock into emitting a beep each time it is opened or closed. Specially developed for environments that are slightly or very noisy, so as to make locking and opening easier to manage. The same card is used to deactivate the sound. Available in two versions to match the technology you have chosen for the lock.

Art. no	Wireless system
371715	Mifare
371341	EM

Technical specifications

Function card - Sound on/off



Specification	Value
---------------	-------